

Instructions for Removing Toe-Space Heater Parts To Be Returned To Factory



**(Required to Receive Rebate or Discount
on New Replacement Heater)**

Step 1. Turn Thermostat to the OFF Position and Disconnect Power to Heater at Electrical Panel (Switch Breaker to OFF or Remove Fuses)



WARNING: *Risk of Electric Shock – Make Sure All Power To Heater Is OFF At Electrical Panel Before Proceeding to Step 2.*

Step 2. Remove Grille by removing the two screws as shown in Fig. 1, (A & B)


Fig. 1



Step 3. Disconnect Heater Plug From Socket By Pulling Apart (See Figs. 2 & 3)
(Grille and Enclosure Top Cover Removed for Clarity)



Step 4. Cut Wires and Remove Heater Plug Assembly As Shown (See Fig. 4)




Step 5. Record the Heater Catalog Number from Nameplate Label (Fig 5) and Complete Customer Information Form

(see website www.berkomep.com/ts.htm or contact factory to obtain forms).


Catalog
Number

Fig. 5 Berko Nameplate Label
(Located Adjacent To Plug And Socket)



Step 6. Return Heater Plug Assembly (Fig 6) And Completed Customer Information Form to Factory for \$25 Rebate or Discount on Purchase of New Heater.

Note: Heater Order Form and Payment Also Required To Purchase New Heater.



Return Address:
for \$25 Rebate or
Replacement Heater Orders

**TS Replacement Program
Marley Engineered Products
470 Beauty Spot Road East
Bennettsville, SC 29512**